



Operating Instructions and Spare Parts List

EasyTronic Control Unit




EASYTRONIC CONTROL UNIT - FRONT VIEW



- 1 Diagnostic LEDs
- 2 Powder output display
- 3 Key for setting the powder output
- 4 Electrode rinsing air key
- 5 Application key for flat parts
- 6 Application key for complicated parts
- 7 Application key for overspraying
- 8 On / Off Push button
- 9 Key for setting the total air volume
- 10 Diagnostic LED for High-voltage
- 11 Total air volume display

CONNECTIONS ON THE REAR OF THE EASYTRONIC CONTROL UNIT



- 1.1 IN Compressed air input
- 1.2 Conveying air connection
- 1.3 Supplementary air connection
- 1.4 Rinsing air connection
- 1.5 Fluidizing air connection
- 2.1 Mains input (85-264 V)
- 2.2 Gun connection for the EasySelect Manual Powder Gun.
*PG 1 manual powder guns **cannot** be connected here!*
- 2.3 Output for Vibrator (EASY 1-B only) and Stirrer control unit (EASY 1-S only)
- ⏏ Ground connection

Table of Contents

Directions for use

Safety rules for electrostatic Powder coating

Technical Data - EasyTronic Control unit

| | |
|---|-----------|
| EasyTronic Control Unit | 1 |
| Field of Application | 1 |
| Operating mode | 1 |
| Description of the EasyTronic Control unit | 2 |
| Installation of the Powder coating equipment | 3 |
| Preparation for Start up | 4 |
| a) Setting the Operating mode on the Electronic board | 4 |
| b) Preparation of the Powder hopper / container | 5 |
| c) Switching on the Booth | 5 |
| d) Function check | 5 |
| Daily Start up | 6 |
| a) Setting the Powder output, and Powder cloud | 6 |
| Set the Total air volume | 6 |
| Select the Powder output volume | 6 |
| Select the electrode rinsing | 6 |
| b) Powder coating | 7 |
| c) Remote control through the Powder gun | 7 |
| d) Switching off | 7 |
| When the Powder coating equipment is not used for a number of days .. | 7 |
| Repairs to Electrical parts of the Control unit | 8 |
| a) Replacing fuse(s) | 8 |
| b) Replacing the CG 01 Printed Circuit Board | 9 |
| c) Replacing the Front plate | 10 |
| Dismantle Main switch | 10 |
| Repairs to Pneumatic parts in the Control unit | 11 |
| a) Replacing a Pneumatic Part | 11 |
| Removing the pneumatic tubes | 11 |
| Replacing the pneumatic tubes | 11 |
| Troubleshooting Guide | 12 |
| Pneumatic diagram | 14 |
| Block Diagram | 15 |
| Display of the Operating Time | 16 |
| Spare parts list | 17 |
| Ordering Spare parts | 17 |
| EasyTronic Control Unit - Pneumatic Parts | 18 |
| EasyTronic Control Unit - electrical Parts | 20 |
| EasyTronic Control Unit - Accessory | 21 |

DIRECTIONS FOR USE

Safety rules for electrostatic Powder coating

1. This equipment can be dangerous when not operated according to the following standards:
EN 50 050 (or VDE 0745 Part 100),
EN 50 053 Part 2 (or VDE 0745 Part 102),
and specification sheet, ZH 1/443 Electrostatic Powder Coating.
2. All electrically conductive parts within 5 m of the coating area, especially the workpieces, must be grounded.
3. The floor in the coating area must be electrically conductive (normal concrete is generally conductive).
4. The operating personnel must wear electrically conductive footwear (i.e. leather soles).
5. The operating personnel should hold the powder gun in the bare hand. If gloves are worn they must be electrically conductive.
6. Connect the grounding cable (green/yellow) supplied to the grounding screw of the electrostatic manual powder coating equipment. The grounding cable must have a good metal to metal connection with the powder coating booth, the powder recovery equipment and the chain conveyor or the hangers of the objects.
7. The electric cables and powder hose to the guns must be laid out so that they are protected from possible mechanical damage.
8. The powder coating equipment must switch on only after the powder booth is in operation. If the booth breaks down, then the powder coating equipment must switch off.
9. The grounding of all conductive parts is to be checked at least once a week.
10. When cleaning the powder gun and when replacing nozzles the control unit must be switched off.

TECHNICAL DATA - EASYTRONIC CONTROL UNIT*Mains connection:*

| | |
|----------------------------------|---------------------------------------|
| Input voltage: | 90 - 264 V |
| Frequency: | 47 - 440 Hz |
| Nominal output voltage (to gun): | max. 12 V _s |
| Nominal output current (to gun): | max. 1 A |
| Type of protection: | IP 54 |
| Temperature range: | 0 °C to +40 °C (+32 °F to +104 °F) |
| Approval: | |

Pneumatic Data

| | |
|--|----------------------|
| Main compressed air input: | B.S.P. 1/4" (Female) |
| Max. Input pressure: | 10 bar |
| Min. Input pressure: | 6 bar |
| Max. water content of the compressed air: | 1.3 g/m ³ |
| Max. oil vapour content of the compressed air: | 0.1 mg/kg |

Dimensions:

| | |
|---------|--------|
| Width: | 248 mm |
| Depth: | 250 mm |
| Height: | 174 mm |
| Weight: | 5.2 kg |

**IMPORTANT**

The EasyTronic Control Unit can only be used with the EasySelect manual gun.

EASYTRONIC CONTROL UNIT

Field of Application

The electrostatic EasyTronic Control Unit is designed exclusively for the controlling powder coating with the EasySelect manual powder gun. This equipment is not to be used for any other purpose. Any damage resulting from its misuse is not the responsibility of the manufacturer, the entire risk is carried by the customer alone.

All settings for efficient powder coating have been made simple and reproducible on the EasyTronic. The built-in electronics permit exact setting of the optimum powder output, and the values set can be seen on the digital display windows and can even be checked from a distance. According to the selected application mode, the spray voltage is set automatically and spray current is limited automatically. The EasyTronic Control Unit can be connected to all usual mains voltages.

For a better understanding of the relationships in powder coating it is recommended to read the operating instructions of other components, thoroughly, so as to be familiar with their functions also.

Operating mode

The EasyTronic Control Unit is foreseen as standard for operation with all manual coating equipment in the EASY range. The desired functionality must, however, be determined by means of a "jumper" on the electronic board inside the control unit. If the control unit is supplied as a component of an EASY unit, then the "jumper" will be correspondingly set in the correct position at the factory.


In every other case, it is recommended to check the setting of the "jumper" (see also the corresponding section "Setting the operating mode on the electronic board").


**NOTICE**

An incorrectly set "jumper" can lead to malfunctioning or to reduced functioning of the Vibration, Fluidization or Stirrer!


DESCRIPTION OF THE EASYTRONIC CONTROL UNIT

The operating panel of the EasyTronic control unit consists of 4 main areas: *Diagnostic LEDs*, *Displays*, *"+/-" Keys*, and *Function keys*.


- 

1. The **Diagnostic LEDs** 1–8 serve to show the status of the equipment, and equipment faults. Detailed information is found in the "Troubleshooting Guide"
 - 

2. There are two **Displays** with whose help the following values are displayed:

 - **Powder output** (Setting range 0–100 %) Powder output in % always refers to the max. possible output volume to the total air volume setting.
 - **Total air volume** (Setting range 1.6–6.0 Nm³/h)
 - 

3. The **Keys "+"** and **"-"** are for setting the powder output, and the total air volume used.

If a key is pressed once, the value is increased or decreases, respectively, by one step. If a key is pressed continuously, the setting change rapidly.
 - 


4. The **Function keys** have the following functions:

 - **Electrode rinsing air for flat jet nozzles**
 - **Electrode rinsing air for round jet nozzles**

When a key is pressed once, the corresponding function is activated, and the corresponding LED illuminates.

If a key with an illuminated LED is pressed for longer than 1 second, the function is deactivated.

ITW Gema recommends leaving the electrode rinsing air switched on, but can, however, remain switched off for applications with very small amounts of powder.

 - **Application keys:** With these keys the electrostatic (High-voltage, and current) are automatically set so that the setting for the selected application is the optimum.
 - Settings for flat parts
 - Settings for complicated parts with depressions
 - Settings for coating parts already coated
- High-voltage and current can be deactivated, when the corresponding key pad with the illuminated LED is pressed for longer than 1 second.

The EasyTronic control unit is switched on and off with a **Push button**. If the equipment is switched on, the yellow lamp is illuminated.




Figure 1

When the equipment is first switched on the preselected factory settings displayed:

60%
Flat jet rinsing

4.0 Nm³/h
Complicated parts

After switching the equipment off (also when the equipment is disconnected from the Mains) the actual settings are retained.

INSTALLATION OF THE POWDER COATING EQUIPMENT

1. Connect the hose for the compressed air supply from compressed air circuit directly to the main air connection - **1.1 IN** on the rear of the control unit (female thread: 1/4" B.S.P.).

NOTICE

The compressed air must be free from oil and water.

2. Connect the black hose for the fluidizing air (if required) to the corresponding output (**1.5**) on the rear of the control unit.
3. Fit the grounding connection cable on the control unit with the grounding screw $\frac{1}{4}$, and the 5 m long grounding cable with the clamping clip to the booth or on the hanger device.
4. Connect the gun cable with the 7 pin plug on the rear of the control unit on the socket - **2.2** (Gun).

IMPORTANT

PG 1 Manual powder guns cannot be connected!

5. Connect the hose for rinsing air to the rinsing air output - **1.4** and to the powder gun.
6. Plug the injector in, and connect the powder hose to the injector and to the powder gun.
7. Connect the red hose for the conveying air to the corresponding output - **1.2** on the rear of the control unit and to the injector.
8. Connect the black hose for the supplementary air to the corresponding output - **1.3** on the rear of the control unit and to the injector.
9. Connect the Mains cable on the socket - **2.1**.




Figure 2

PREPARATION FOR START UP

a) Setting the Operating mode on the Electronic board



The Mains plug of the EasyTronic Control Unit must be disconnected from the Mains before starting work!

The desired operating mode must be determined with a so-called "jumper" the electronic board inside the control unit.



If the control unit is supplied as a component of an EASY unit, then the "jumper" will be correspondingly set in the correct position at the factory.

1. Unscrew the screws on the front of the housing.



Figure 3

2. Hold the front plate with one hand and fit the "jumper" in the desired position:





Figure 4

3. Replace the front plate and tighten the screws.
Do not over-tighten the screw!
4. Reconnect the Mains cable.
5. Carry out a calibration:

- a) Hold all Application keys  pressed and simultaneously press the Main switch.

The equipment carries out a calibration. An increase in noise can be heard inside the control unit. Both displays show 888. After about 20 seconds the equipment is ready for operation and returns to the factory setting.

b) Preparation of the Powder hopper / container

Prepare the powder hopper or the powder container according to the type of manual equipment to be used.
(Follow the instructions in the corresponding operating manuals)

c) Switching on the Booth

Switch on the powder coating booth according to the corresponding operating instructions.

d) Function check

1. Press the push button on the control unit. The yellow control lamp in the switch illuminates.
The equipment carries out a calibration, when it comes **direct from the factory**. An increase in sound can be heard inside the control unit. Both displays show *888*. The equipment is ready for operation after about 20 seconds and switches to the factory settings.
2. Take the powder gun in the hand and point it at a **grounded** object in the booth, distance approx. 20 cm.
3. Press the gun trigger.
LED No. 8 illuminates. The High-voltage is switched on and powder is conveyed.

If all tests are positive, the control unit, and the powder gun are ready for operation. If one of the functions does not operate as expected, check this in the "Troubleshooting Guide", on page 12.

DAILY START UP**a) Setting the Powder output, and Powder cloud**

The powder output is dependent on the powder, and the setting of the total air volume.

Set the Total air volume

1. Switch on the control unit.
2. Set the total air volume (for more information, also see the EasyFlow Operating Instructions).

The total air volume is dependent on the powder hose length, the number of turns of the hose, the hose diameter, and the object being coated.

The value set for the total air volume can be left as it is, as long as the same powder hose is used. If the hose length and/or the hose diameter are changed, then the total air volume must be reset.

Select the Powder output volume

3. Select the powder output volume according to the desired coating thickness.

The selection takes place with the aid of the + or – keys, either on the control unit or on the rear of the powder gun.


To start, a standard setting of 60% is recommended. The total air volume is maintained constant automatically.

4. Check the fluidizing of the powder
5. Point the powder gun into the booth and press the powder gun trigger


Select the electrode rinsing

6. Select the correct electrode rinsing

When using flat jet nozzles:

- Press the key with the corresponding symbol . The LED of the corresponding key illuminates.

When using round jet nozzles with air rinsed deflector plates:

- Press the key with the corresponding symbol . The LED of the corresponding key illuminates.

7. Adjust the powder cloud to a test object

When using flat jet nozzles:

- Unscrew the threaded sleeve approximately 45°, so that the flat jet nozzle (or extension) can only be turned slightly
- Turn the flat jet nozzle to the desired axial position
- Tighten the threaded sleeve again


When using round jet nozzles with air rinsed deflector plates

- Exchange the deflector plate (ø 16, 24, and 32 mm supplied with the powder gun)

b) Powder coating

Make sure that all electrically conductive parts within 5 m of the coating booth are grounded!

1. Take the powder gun in hand and point it into the coating booth, however, do not point it at an object to be coated yet
2. Select the application setting

Press the corresponding application key  on the control unit. The LED of the corresponding key illuminates.

3. Press the powder gun trigger
4. Coat the object(s)

c) Remote control through the Powder gun

The different functions can be remotely controlled with the aid of the + and – keys on the rear of the powder gun:

1. Select the application setting

*Press the + and – keys on the powder gun **simultaneously***

Check by observing the LED display on the powder gun:

Red = Flat parts

Green = Complicated parts

Red/Green (alternating) = Spraying over

2. Change the powder output

Press the + or – keys on the powder gun. The powder output is correspondingly increased or decreased.

d) Switching off

1. Release the powder gun trigger
2. Switch off the control unit

The settings for high-voltage, rinsing air, and powder output are retained.

When the Powder coating equipment is not used for a number of days:

1. Remove the Mains plug from the Mains
2. Clean the coating equipment, see corresponding operating instructions
3. Turn off the main compressed air supply

REPAIRS TO ELECTRICAL PARTS OF THE CONTROL UNIT



The Mains plug of the EasyTronic Control Unit must be disconnected from the Mains before starting work!

a) Replacing fuse(s)

1. Unscrew the screws on the front of the housing.
2. Hold the front plate with one hand and remove the fuse(s) (quick-acting) from the fuseholder and replace with a new one.





Figure 5

3. Replace the front plate.
Do not over-tighten the screws!
4. Reconnect the Mains cable.
5. Carry out a calibration:

a) Hold all Application keys  pressed and simultaneously press the Main push button.

The equipment carries out a calibration. An increase in noise can be heard inside the control unit. Both displays show 888. After about 20 seconds the equipment is ready for operation and returns to the factory setting.

b) Replacing the CG 01 Printed Circuit Board

1. Disconnect all electrical and pneumatic connections on the rear of the control unit.
2. Loosen the clamping element, dismantle the control unit and place on an level surface.
3. Unscrew the screws on the front of the housing.
4. Press the spacers together with pointed pliers and remove the printed circuit board
5. Remove the plug from the defective board and replace it on the new board.
6. Place the new board on the spacers and push them until they snap into place.
7. Reassemble the control unit in reverse order as described above.





Figure 6

8. Reconnect the Mains cable
9. Carry out a calibration:
 - a) Hold all Application keys  pressed and simultaneously press the Main push button.

The equipment carries out a calibration. An increase in noise can be heard inside the control unit. Both displays show 888. After about 20 seconds the equipment is ready for operation and returns to the factory setting.

If there are any problems or uncertainties, please contact a ITW Gema Service Centre.

c) Replacing the Front plate

Dismantle Main switch

1. Disconnect all electrical and pneumatic connections on the rear of the control unit.
2. Loosen the clamping element, dismantle the control unit and place on an level surface.
3. Unscrew the screws on the front of the housing.
4. Disconnect all plugs from the front plate.
5. Unscrew the screws on the black ring and unscrew the ring.
6. Push the switch through the hole.



Figure 7

7. Unscrew the aluminium ring (A) and pull the push button out of the front plate.




Figure 8

8. Replace the front plate.
9. Fit the plugs to the new front plate.




With the plug **X10**, take note of the white marking!

10. Reassemble the front plate and control unit in the reverse order as described above.

Do not over-tighten the screw!

11. Reconnect the Mains cable.
12. Carry out a calibration:

- a) Hold all Application keys  pressed and simultaneously press the Main push button.

The equipment carries out a calibration. An increase in noise can be heard inside the control unit. Both displays show 888. After about 20 seconds the equipment is ready for operation and returns to the factory setting.




Figure 9

If there are any problems or uncertainties, please contact a ITW Gema Service Centre.

REPAIRS TO PNEUMATIC PARTS IN THE CONTROL UNIT

a) Replacing a Pneumatic Part

1. Disconnect all electrical and pneumatic connections on the rear of the control unit.
2. Loosen the clamping element, dismantle the control unit and place on an level surface.
3. Unscrew the screws on the front of the housing.
4. Remove all pneumatic tubes from the part to be replaced (see below).
5. Dismantle the defective part and replace.
6. Reconnect the pneumatic tubes (see below).
7. Reassemble the control unit in the reverse order as described above.

If there are any problems or uncertainties, please contact a ITW Gema Service Centre.

Removing the pneumatic Tubes

Before exchanging pneumatic parts all tube connections should be removed. This is done by pushing the pressure ring back, with the thumb nail, on the quick-release fitting of the tube connector. The tubing can now be withdrawn.




Figure 10

Refitting the pneumatic tubes

This is done by pushing the plastic tubing as far as it will go into the quick-release fitting of the hose connector. The hose is now fixed securely.




Figure 11

TROUBLESHOOTING GUIDE

The diagnosis LEDs 1-7 illuminate green when switched on, and LED 8 remains unilluminated. It illuminates red when the gun trigger is pulled.


| Fault | Cause | Remedies |
|--|--|--|
| LED 1-3 not illuminated | Mains supply unit defect | Replace Mains supply unit |
| LED 4 illuminates red | Main valve defect | Replace main valve spool |
| LED 5 illuminates red | <ul style="list-style-type: none"> - Gun not connected - Gun plug, gun cable or gun cable connection defect - Remote control on the gun defect | <p>Connect the gun</p> <p>Replace corresponding part or send in for repair</p> <p>Exchange remote control (gun cover)</p> |
| LED 6 illuminates red | Solenoid for rinsing air of the flat jet nozzle defect | Replace solenoid valve spool |
| LED 7 illuminates red | Solenoid for rinsing air of the round jet nozzle defect | Replace solenoid valve spool |
| LED 8 not illuminated, in spite of the trigger being pulled and the LED 5 illuminates green. | Gun plug, gun cable or gun connection defect | Replace corresponding part or send in for repair |
| The gun LED remains unilluminated, in spite of the trigger being pulled, and the LED 8 illuminates red. | <ul style="list-style-type: none"> - Gun plug, gun cable or gun connection defect - Remote control on the gun defect | <p>Replace corresponding part or send in for repair</p> <p>Exchange remote control (gun cover)</p> |
| Powder does not adhere to the object, in spite of the trigger being pulled, and the gun sprays powder, the gun LED, and the LED 8 are illuminated. | <ul style="list-style-type: none"> - High-voltage and current deactivated - High-voltage cascade defect. - The objects are poorly grounded. | <p>Press the selection key (Application key)</p> <p>Send the gun in for repair</p> <p>Check grounding, see also "Safety rules"</p> |
| The control lamp in the push button does not illuminate in spite of the control unit being switched on. | <p>No current:</p> <ul style="list-style-type: none"> - Control unit is not connected to the Mains. <p>In the equipment:</p> <ul style="list-style-type: none"> - Bulb burnt out. - Power pack defect | <p>Connect the mains cable to the unit</p> <p>Replace</p> <p>Replace</p> |

(continued)

Troubleshooting Guide (cont.)

| Faults | Causes | Remedies |
|---|--|---|
| <p>The powder is not fluidized.</p> | <p>No compressed air present</p> <ul style="list-style-type: none"> - Reducing valve closed - Reducing valve defect | <p>Connect the equipment to the compressed air supply</p> <p>Open</p> <p>Replace</p> |
| <p>The gun does not spray powder in spite of the control unit being switched on and the gun trigger being pressed</p> | <p>No compressed air present</p> <ul style="list-style-type: none"> - Injector, check valve or nozzle on the injector, powder hose or gun clogged - Nozzle in the injector clogged - Nozzle not fitted - Fluidizing does not function <p>No conveying air:</p> <ul style="list-style-type: none"> - Reduction valve defect - Solenoid valve defect - Electronic in the front plate defect | <p>Connect the equipment to the compressed air supply</p> <p>Clean corresponding part</p> <p>Replace</p> <p>Fit nozzle</p> <p>See above</p> <p>Replace</p> <p>Replace</p> <p>Replace, send in for possible repair</p> |

PNEUMATIC DIAGRAM



S1 = Rinsing air unit
 M1 = Throttle motor
 E1 = Input unit

Figure 12

BLOCK DIAGRAM





Figure 13

DISPLAY OF THE OPERATING TIME

A software type Timer is built into the EasyTronic Control Unit which gives information about how long the control unit has been used for coating.

In order to use this function the unit must be switched on and **both rinsing air keys**  **must be pressed simultaneously.**

This switches the display and the operation time can be read.

The display shows the hours, with a definition of 1/10 h = 6 mins.

The maximum operating time is 99999.9 h.

The Timer cannot be reset.

SPARE PARTS LIST

Ordering Spare parts

When ordering spare parts for powder coating equipment, please indicate the following specifications:

1. Type and serial number of your powder coating equipment
2. Order number, quantity, and description of *each* spare part

Example:

1. **Type** *EasyTronic*, **Serial No.:** *XXX XXX*
2. **Order No.:** *201 073, 5 pieces, Fine wire fuse*

When ordering cable and hose material the length required must be given.

The spare part numbers of yard/meter ware always begins with 1.. ... and are always marked with an * in the spare parts list.

Wear parts are always marked with a #.

All dimensions for plastic powder hoses are given as external diameter (o/d) and internal diameter (i/d):

e. g. \varnothing 8 / 6 mm, 8 mm outside diameter / 6 mm inside diameter (i/d).

EASYTRONIC CONTROL UNIT - PNEUMATIC PARTS

| | | |
|----|---|---------|
| 2 | Valve support | 265640 |
| 5 | Pressure regulating valve - 5 bar (preset) | 262269 |
| 6 | Solenoid valve - 1/4" - NW 8 mm, 24 VDC | 262307 |
| 7 | Solenoid valve - 1/8" NW - 1.6 mm, 24 VDC | 262285 |
| 8 | Solenoid valve spool - 24 VDC | 262293 |
| 11 | Seal | 262900 |
| 12 | Drive unit | 375713 |
| 13 | Rinsing air unit - S1 | 375730 |
| 14 | Aluminium Block without solenoid | 263869 |
| 15 | Solenoid | 263850 |
| 28 | T-Connection - \varnothing 8 - \varnothing 8 - \varnothing 8 mm | 258040 |
| 29 | Plastic hose - \varnothing 8 / 6 mm | 100005* |

* Please indicate length required

Wear parts

EasyTronic Control Unit - Pneumatic Parts





Figure 14

EASYTRONIC CONTROL UNIT - ELECTRICAL PARTS

| | | |
|------|---------------------------------------|---------|
| 2 | Front plate - complete | 375 799 |
| 4 | Clamping element - complete - ø 30 mm | 376 183 |
| 10 | Printed circuit board CG 01 | 374 059 |
| 10.1 | Fuse - 4 AF, 250 V | 262 897 |



* Please indicate length required

Figure 15

EASYTRONIC CONTROL UNIT - ACCESSORY

The transparent protective cover can be simply snapped onto the EasyTronic Front Panel and protects it from contamination and damage. All key pads (incl. the On/Off Switch) can be operated through the protective cover.

Snap-on Protective Cover (set of 5 pieces)

265284



Figure 16

Documentation EasyTronic

© Copyright 2000 ITW Gema AG., CH-9015 St. Gall
All rights reserved.

This publication is protected by copyright. Unauthorized copying is prohibited by law. No part of this publication may be reproduced, photocopied, translated, stored on a retrieval system or transmitted in any form or by any means, for any purpose, neither as a whole nor partially, without the express written consent of ITW Gema AG.

OptiTronic, OptiGun, EasyTronic, EasySelect, EasyFlow and SuperCorona are registered trademarks of ITW Gema AG.
OptiMatic, OptiMove, OptiMaster, OptiPlus, OptiMulti and Gematic are trademarks of ITW Gema AG.

All other product names are trademarks or registered trademarks of their respective holders.

Reference is made in this manual to different trademarks or registered trademarks. Such references do not mean that the manufacturers concerned approve of or are bound in any form by this manual. We have endeavoured to retain the preferred spelling of the trademarks, and registered trademarks of the copyright holders.

To the best of our knowledge and belief, the information contained in this publication was correct and valid on the date of issue. ITW Gema AG makes no representations or warranties with respect to the contents or use of this publication, and reserves the right to revise this publication and make changes to its content without prior notice.

Printed in Switzerland

ITW Gema AG
Mövenstrasse 17
9015 St. Gall
Switzerland

Phone: +41-71-313 83 00
Fax: +41-71-313 83 83
E-mail: info@itwgema.ch